


Instructions for set up of PCB for NDD models

(230148 ["A" models] & 230188 [standard models])

1) Ensure that once the new PCB is fitted that you follow the following instructions	Running the machine at this stage WITHOUT fitting a restrictor will cause the circuit board to calibrate incorrectly!
2) Fit a "blanking cap" modified to have an 18mm hole (see picture) to the drum of the machine	
3) Switch machine on once 18mm "restrictor" cap is fitted to drum	4) Run machine for approximately 10 seconds (or until machine stops / light flashes repeatedly)
5) Switch machine to off and remove "restrictor" cap from drum	6) Machine has been calibrated and PCB set up complete