



1	PA-A7004	Fan Cover
2	PA-A7005	Screw, ST4*12mm
3	PA-A7006	Gasket
4	PA-A7007	Fan Holder
5	PA-A7008	Fan
6	PA-A7009	Screw, M4*12
7	PA-A7010	Spring Washer
8	PA-A7011	Control Panel Cover
9	PA-A7012	Fan Speed Switch (No Knob)
10	PA-A7013	Filter Replacement Indicator
11	PA-A7014	Outlet
12	PA-A7015	Screw, M3. 5x10mm
13	PA-A7016	Switch Knob
14	PA-A7017	Switch, UV-C Light

15	PA-A7018	Switch, Circuit Breaker
16	PA-A7019	Hour Meter
17	PA-A7020	Housing
18	PA-A7021	Door Switch
19	PA-A7022	Cord Wrap
20	PA-A7023	Screw, M4*10
21	PA-A7024	Latch
22	PA-A7025	Outlet Grill
23	PA-A7026	Foot
24	PA-A7027	Screw, ST4*14mm
25	PA-A7028	Air Deflector
26	PA-A7029	Strain Relief
27	PA-A7030	UV-C Lamp
28	PA-A7031	Screw, ST4*10mm
29	PA-A7032	Foam Gasket Seal
30	PA-A7033	Flat Washer, 5*16*1.5mm

31	PA-A7034	Spring Washer, 5mm
32	PA-A7035	Screw, M5*22
33	PA-A7036	Fan Retainer Grill
34	PA-A7037	Flat Washer, 4*12*1mm
35	PA-A7003	HEPA Filter (H13)
36	PA-A7002	Carbon (Charcoal) Filter
37	PA-A7001	Pleated Pre-Filter (G4)
38	PA-A7038	Spacer
39	PA-A7039	Filter Clamp
40	PA-A7040	Door
41	PA-A7041	Hinge
42	PA-A7042	Inlet Ring
43	PA-A7043	Inlet Cover
44	PA-A7044	Inlet Cover String
45	PA-A7045	Clip
46	PA-A7046	Hex Nut, M4
47	PA-A7047	Power Cord
48	PA-A7048	Control Board
49	PA-A7049	Screw, ST4*8mm