



## Instruction Manual



### SAFETY FIRST

THANK YOU FOR SELECTING OUR PATRON LIGHTING PRODUCT. PLEASE TAKE A MOMENT TO REVIEW THIS MANUAL BEFORE, INSTALLING, OPERATING OR SERVICING YOUR PRODUCT.

THE LIGHT SHOULD NOT BE USED OTHER THAN THE APPLICATIONS LISTED IN THIS MANUAL. FAILURE TO DO SO MAY LEAD TO A MALFUNCTION OR AN ACCIDENT TO WHICH THE MANUFACTURER WILL NOT ASSUME ANY LIABILITY.

AFTER READING THIS OPERATION MANUAL, KEEP IT IN A LOCATION WHERE IT CAN BE REFERRED TO DURING THE OPERATIONAL LIFE OF THE EQUIPMENT.


IN THE EVENT THE PRODUCT IS DAMAGED, PLEASE CONTACT YOUR AUTHORIZED LOCAL DEALER OR SALES REPRESENTATIVE.

	<b>DANGER:</b> Care should be taken when using this equipment. Using the light incorrectly may result in injury or death.
	<b>WARNING:</b> Failure to observe safety rules may result in Injury, Fire, Electrical shock.

Our L-400 light is rated for indoor/outdoor use. Please follow the safety practices stated in this manual, and use best safety practices to avoid any personal injury, fire or electrical shock. Some good safety practices to keep in mind:

- When using our lights in a wet location, a GFCI (Ground Fault Circuit Interrupter) should be provided on outlets and circuits.
- Avoid using our light where water accumulates. Keep plugs dry.
- When using an extension cord, use only outdoor rated cords that are three prong outlet with ground. Please only use extension cords which are 18AWG or thicker.
- Do Not look directly at the bright light to avoid eye injuries.
- Do Not operate light near flammable liquid, material or surfaces.
- Do Not operate if any part of the light is broken.

# Assembly Instructions



1. Loosen the screw on the (1) trolley, insert the (2) Two Stage Telescopic Mast, then tighten the screw on the (1) trolley.
2. Install the Light T-bar (3) of the lighting fixture into the (2) Two Stage Telescopic Mast, then tighten the T-Handle on the (4) T-bar.
3. Mount the (5) power supply box onto the (2) Two Stage Telescopic Mast. Loosen the four (6) M5 nuts, position the (7) bracket approximately 150 mm above the highest point of the (8) trolley, then re-tighten the four (6) M5 nuts to secure it.

## Operation

- Plug into power supply and turn on the switch. (Use only 120V AC power)
- Rotate the (10) handle on the Two Stage Telescopic Mast clockwise to raise the mast.
- To lower the pole, rotate the (10) handle counterclockwise.
- When operating the trolley on a slope, make sure to engage the (11) brake.
- Use the (12) plug on the power box to connect additional lighting fixtures.
- Always switch off the light before unplugging the lighting fixture.



**Warning:** Risk of personal injury. To avoid being burned, always allow the work light to cool before handling.